

## Login on i-c4c (redesign) through Wi-Fi

Remark: Mobile data should be disabled on smartphones/tablets.

Remark: Only one device can connect to the i-c4c at the same time.

### Select the right Wi-Fi network

Open your network settings and select the Wi-Fi-network of the i-c4c. The name of the network starts with "IC4C" followed by the serial number of the module. Contact your supplier for the Wi-Fi password:



### What if the module is connected to a Wi-Fi display?

In case your i-c4c module is already connected to another device, it will no longer be possible to access the original network. However, the i-c4c comes with a solution for that.

When you try to connect to the network, the i-c4c temporarily creates a new network with the name "IC4C\_DEF" followed by a number. You can now connect to this network using the default password: **incosa\_ic4c** (This is not the same password as for the original i-c4c network.)

If you disconnect from this network, the original network will reappear after 60s.



## Open a webpage

When you are connected to the original or temporary generated network of the i-c4c, you can open a webpage and go to the address "192.168.1.1". After the page has been successfully loaded, you can see a virtual representation of the i-c4c. Using the virtual buttons, you can execute the same actions as on the physical i-c4c. If prompted for a pin code, it is standard "0000".

