


Installation guide

inVision

INVISION

Mounting instructions




1. Use the included mounting sticker, to position the bracket on the preferred spot. It is advised to use at least 4x M8 bolts with washer.




2. Provide bolt thread on the right side of each mounting position.
3. Provide bolt thread on the left side of the middle position.
4. Partially mount the 3 bolts with washer in the right side holes.
5. Place the display over the bolts (1) and shift it to the left so that the bolts hold the display (2).



6. Use the 4th screw to lock the position of the display (3).



7. Change the bracket to the preferred angle and fixate it using the middle nut (Size 13) on each side of the bracket.




Connections

Antenna

Wifi antenna (2.4GHz), RP SMA connection


Spare

CAN OUT, M12 A-coded connection, Female (optional)




Ethernet

Ethernet, M12 D-coded connection



CAN

CAN IN, M12 A-coded connection, Male



Power supply
90-240 VAC
30W

Power, M12 S-coded connection, Male
(Optional: 48VAC)

